



Item	SPARE PART
1	air deflector
2	air deflector plug-ins
3	air deflector support
4	front lining pannel support
5	front lining pannel
6	back pannel
7	front pannel
8	side pannel
9	air deflector jam
10	bearing ring
11	support
12	fan
13	motor support
14	motor fixing plate
15	iron ring
16	motor support mat
19	motor supoort connector
17	motor
18	power cable
20	remote controller pannel
21	pannel
22	capacitance
23	power panel
24	remote controller